

Touch-screen sulla linea Cooker

NEW



serie 
COOKER

- **98 programmi** memorizzabili
- **9 fasi di lavorazione**
- **4 fasi con gestione indipendente di velocità e tempo** di mescolazione
- **Fase gestita a scelta da temperatura o tempo**
- Funzione di **Rotor-Swing**
- **Possibilità di modificare i parametri durante la lavorazione**
- Fino a **12 velocità orarie e 4 antiorarie**
- Gestione **avvio ritardato**
- **Controllo** dell'usura **olio termico** con avviso di manutenzione per cambio olio
- **Risparmio energetico** grazie al dispositivo di controllo della potenza di assorbimento elettrico
- Uso **semplice ed intuitivo**
- **Ricette protette da password**
- **Chiavetta di salvataggio**

Touch keyboard on Cooker

- **98 storing recipes**
- **9 phases for each working cycle**
- **4 phases for speed and mixing time**
- **Function phase controlled by temperature or time**
- **Rotor-Swing** function
- **Data control in working time**
- Up to **12 clockwise speeds and 4 anticlockwise speeds**
- **Automatic start**
- **Alarm for thermic oil maintenance**
- **Energy saving function**
- **Simple and immediate use**
- **Password protected recipes**
- **Key port saving programs**